


Nikon EM




This text is identical to the Owner's manual.


I. Nomenclature



- | | |
|-------------------------------------|--|
| 1. Frame counter; | 13. Lens release button; |
| 2. Shutter operation mode selector; | 14. Reflex mirror; |
| 3. Shutter release button; | 15. Aperture direct readout (ADR) scale**; |
| 4. Shutter release fingerguard; | 16. Lens aperture scale; |
| 5. Film winding lever; | 17. Lens aperture ring; |
| 6. Battery power check button; | 18. Lens mounting ring; |
| 7. Battery power LED lamp; | 19. Aperture/distance scale index; |
| 8. Neckstrap eyelet; | 20. Infrared photography focusing index; |
| 9. Exposure compensation button; | 21. Depth of-field indicators; |
| 10. Self-timer; | 22. Focusing distance scale; |
| 11. Lens mounting flange; | 23. Lens focusing ring; |
| 12. Lens mounting index; | |



- | | |
|--|----------------------------|
| 24. Film rewind crank; | 33. Film cassette chamber; |
| 25. Film rewind knob; | 34. Film rewind fork; |
| 26. ASA film speed selector ring; | 35. Film guide rails; |
| 27. ASA film speed setting index; | 36. Shutter curtains; |
| 28. ASA film speed scale; | 37. Film sprockets; |
| 29. Flash unit hot shoe; | 38. Film takeup spool; |
| 30. Hot-shoe contact; | 39. Film pressure plate; |
| 31. Ready-light contact for SB-E/SB 10 Speedlight; | 40. Camera back; |
| 32. Viewfinder eyepiece; | 41. Memo holder; |



- | | |
|-----------------------------------|---|
| 42. Motor drive positioning hole; | 45. Tripod/motor drive coupling socket; |
| 43. Motor drive coupling; | 46. Battery chamber lid/battery clip; |
| 44. Film rewind button; | 47. Motor drive electrical contact. |

II. Basic Operation



1. Unlock battery chamber 46.




2. Insert two silver-oxide batteries or one lithium battery into battery clip with the "+" sign(s) up.



3. Mount lens after closing battery chamber.



4. Pull out film rewind knob 25 to open camera back 40.



5. Load film. To ensure proper film winding, make sure that both edges of the film engage the film sprockets 37.



6. Rotate film rewind crank 24 take up film slack. Be careful that you do not wind film back into the cassette.



7. Snap camera back closed, then set ASA by lifting up and turning ASA film speed selector ring 26.




8. Set shutter operation mode selector 2 to **AUTO**.



9. Press shutter release button 3 all the way.
Note: Do not attempt to take pictures prior to frame 1, the start of **AUTO** operation.



10. Stroke film winding lever 5 to advance film.



11. Confirm film advance: film rewind knob 25 turns opposite engraved arrow as winding lever is stroked.



12. Repeat Steps 9 and 10 until frame counter 1 indicates "1". Camera is then ready to take first picture.



13. Look through viewfinder eyepiece 32 and focus on subject.



14. Switch meter on, lightly pressing shutter release button 3. Turn lens aperture ring 17 until "beep-beep" sound, if any, stops.



15. You are now ready to shoot: depress shuttle release button until you hear the click of the shuttle.



16. Advance film to the next frame.



17. After completing the roll rewind and unload film.

III. How to Hold the Camera

To take good pictures, you should first learn how to handle your camera properly. Hold the camera with both hands, as shown in the pictures, cushioning it in the palm of your left hand. For added support, prop your left-hand elbow against your body. Before loading the camera with film, practice in front of a mirror until you have mastered all the controls.



Exposure compensation button 9: Depressed with the left hand index finger.

IV. Setting Up the Camera Body and Lens

A. Install the Batteries



Proper batteries: Two 1,55V silver oxide types (S-76, SR-44 or equivalent) or one 3V lithium battery.



1. Unlock the battery chamber lid **46** with a coin.



2. Remove the battery clip which is integral with the lid.




3. Insert the battery (batteries), with the “+” sign(s) facing up, into battery clip.



4. Replace the battery chamber clip/lid, and close the chamber securely.



5. Push the battery power check button **6**. If the adjacent lamp does not light up (or is too dim), check battery orientation or put in a new set of batteries.



Q: Can I still use the camera even when the batteries are dead?

A: Yes. In this case, reset the shutter operation mode selector **2** from **AUTO** to **M90** which will provide a shutter speed of 1/90 sec.

B. Mount the Lens

Proper lenses: Nikon Series E lenses, AI-type Nikkor lenses and others (see list).



1. Remove the camera body.



2. Remove the rear lens cap.



3. Seat the lens on top of the camera body's lens mounting flange **11**, making sure the lens mounting index **12** is aligned with the aperture/distance scale index **19**. Then twist the lens by its mounting ring **18** until it clicks and locks into place.



4. To remove the lens: Press the camera's lens release button **13**, and twist the lens clockwise by its mounting ring until it becomes loose.

V. Preparing to Shoot and Actual Shooting

Proper film: Any commercially available, color or black-and-white, 35mm film negative (prints) or transparency (Slides) in cassettes of 12, 20, 24 or 36 exposures.

A. Load the Film



1. Open the camera back by pulling up the film rewind knob **25**.



2. Place the cassette in the film cassette chamber **33**.



3. Secure the cassette with the film rewind fork **34** by pressing the knob back.



4. Insert the film leader into any of the film take-up spool's **38** six slots. Be sure the film's perforations engage the film sprockets **37**. Press the shutter release button and stroke the film winding lever to advance the film.



5. After closing the camera back, press the shutter release button ③.



6. To take up film slack, turn the film rewind crank 24 in the direction of the engraved arrow, until you feel a slight resistance. Be careful not to wind the film back into the cassette.



7. Advance the film, press the shutter release button and advance the film again until the frame counter ① indicates "1" to start AUTO operation.



Q: How can I be sure the film has been properly loaded and is being advanced?

A: If, as you advance the film winder lever, the film rewind knob rotates in the opposite direction of the arrow engraved on it, you can be sure the film is being properly advanced.

Note: If you release the shutter during "AUTO" operation with the cap mounted on the lens or in an extra dark place, the reflex mirror ⑭ will remain in the "up" position. To return the mirror to its original position, set the shutter operation mode selector ② to M90 or B.

B. Set ASA



1. Pull up the ASA film speed selector ring 26.



2. Turn it until the ASA film speed setting index 27 is aligned with your film's ASA rating.



Note: Don't forget to reset ASA when you use film with different ASA ratings; otherwise, the film will not be correctly exposed.

Q: What is ASA?

A: ASA is a number which indicates the relative sensitivity of your film to light. Your camera must have this information to be able to give your film the proper exposure.

Q: What should I do to remember the ASA rating of the film loaded in the camera?

A: As a reminder, insert the film carton tab which indicates the ASA rating, into the camera back's memo holder 41.

C. Focus



1. Aim your camera at your subject, then compose the picture through the viewfinder.




2. Rotate the lens focusing ring 23 until your subject appears in the viewfinder.



Out of focus



In focus



- ① Shutter speed scale
- ② Flash ready-light
- ③ Flash photography bracket
- ④ Shutter speed needle
- ⑤ Split-image range finder spot
- ⑥ Microprism ring
- ⑦ Fine matte outer field

Split-image rangefinder spot ⑤: Suitable for subjects with well-defined outlines. Turn the focusing ring 23 until the two halves of the spot coincides, forming a single image.

Microprism ring ⑥: For subjects without definite contours, or for rapid focusing. Turn the focusing ring until the image in the ring appears crisp.

Fine matte outer field ⑦: Ideal for close-ups or when shooting with telephoto lenses. Turn the focusing ring until the image in the field appears sharp.

To “prefocus” the lens (i.e., when time does not permit focusing through the viewfinder), turn the focusing ring until the estimated distance is aligned with the lens aperture/distance scale index 19. With this technique, however, the focus may not be as sharp as you expect.



Note: When you're using lenses with small maximum apertures (e.g., *f/5.6*, *f/8*) or taking close-ups, you may find it difficult to focus with the split-image spot or microprism ring (i.e., they become “dark”); in this case, focus with the fine matte outer field.

D. Determine Exposure



1. Set the shutter operation mode selector ② to AUTO.



2. Select an aperture by turning the lens aperture ring ⑬.



3. Press the shutter release button ③ halfway (i.e., cushion your finger with the shutter release fingerguard ④) to switch the camera's meter on. The shutter speed indicated by the needle ④ in the viewfinder will depend on both the selected aperture and scene brightness.

Note: The meter remains switched on for a brief period even after your finger is lifted off the shutter release button.

Exposure warning signal: Should a “beep-beep” sound be emitted, note the position of the needle in the shutter speed scale. If it swings past 1/1000 sec. and stays within the red zone, overexposure will result. In this case, reset lens aperture until the sound stops or the needle “drops” from the red zone; despite the sound, correct exposure is possible. If the needle is around 1/30 sec. or below, the sound merely warns you that camera shake may affect image sharpness because of the slow shutter speed. You either read - just aperture until the sound stops, or, if the needle is below 1/30 sec., use a tripod to prevent picture blur. The meter remains switched on for a brief period even after your finger is lifted off the shutter release button.

Notes: 1. At approximately 1/1000 sec. or 1/30 sec., a shrill sound may be emitted; it becomes regular when the beyond these points.
2. It is possible you won't hear the warning sound in noisy shooting situations.



Overexposed
(above 1/1000 sec.)



Tripod recommended to
prevent camera shake
(below 1/30 sec.)




Correctly exposed

Q: What shutter speed is best to use?

A: The shutter speed should be fast enough to prevent camera shake, especially in hand-held shooting. In dim light, you may not be able to get a high speed. As a rule of thumb, use a tripod if the shutter speed is slower than a number equal to the focal length of the lens. For example, with a 50 mm lens, don't take hand-held pictures at shutter speeds slower than 1/50 sec., and with a 135 mm, try to use a minimum speed of 1/135 sec. Remember, this presumes your subject is not moving. If it does, you'll need faster speeds — in which case you just open the lens aperture.


E. Shoot



1. Depress the shutter release button **3** with steady, even pressure.



2. Advance the film to the next frame by stroking the film winding lever **5**.



You can move the grooved winding lever with your right-hand thumb in one sweep or a series of short strokes.

Self-timer: This provides an approx. 10-sec. exposure delay. Slide the lever **10** away from the lens as far as it will go, cover the finder eyepiece **32** with the palm of your hand to prevent stray light from entering, then depress the shutter release button **3**. Note that the timer is designed not to cock accidentally and requires slight pressure when you start to stroke it. After use, gently nudge the lever back into place since it always stops just before the starting position.



Q: When is the exposure compensation button **9** used?

A: To obtain a correct exposure when the main subject is side lit or backlit. In this case, keep the button depressed as you depress the shutter release button **3**, the shutter speed needle “drops” by about 2 steps (i.e., from 1/250 sec. to approx. 1/60 sec.).

F. Unload the Film



1. When you can no longer stroke the film winding lever and the frame counter **1** indicates that the last exposure has been made, press the film rewind button **44**. Don't force the lever, or you may tear the film out of the cassette.



2. Turn the film rewind crank **24** in the direction of the engraved arrow with even pressure until rewind “tension” gets lighter.



3. Pull up the film rewind knob **25** to open the camera back, and remove the cassette.

Notes: 1. Do not push the film rewind button before all the frames are exposed; otherwise, there will be a slight frame overlap. If the button is inadvertently depressed make a blank exposure in a dark place.

2. When carrying the camera, it is recommended that you reset the shutter operation mode selector ② from **AUTO** to **B** to prevent battery power drainage caused by the shutter release button being inadvertently depressed.




Q: What should I do if I make the mistake of opening the camera back before the film is fully rewound?

A: Quickly snap the camera back closed. You may be able to save a few frames, but this is not guaranteed, especially if the back is opened in bright light.

VI. Technical Details and Other Information

A. Exposure Measurement

The Nikon EM's built-in exposure meter uses Nikon's through-the-lens (TTL) center-weighted exposure metering system. The meter "reads" the light over the entire focusing screen, but favors the central 12mm-diameter area outlined on the screen. This is where the main subject is likely to be positioned, and allows the photographer to make precise exposure readings of the selected subject area, as well as provides for overall balanced exposures.



B. Shutter Operation Mode Selection

The shutter operation mode selector has two mechanical override settings. **M90** provides a shutter speed of 1/90 sec., it is also used for flash photography with an electronic flash unit other than the Nikon SB-E or SB-10. **B** is for long exposures — the shutter curtains remain open for as long as the shutter release button ③ is kept depressed. A tripod is essential for **B** exposures.



C. Film Plane Indicator

This is mainly used in close-up photography to determine the exact subject-to-film plane distance. It is visible when the film winding lever ⑤ is pulled out, and positioned precisely on the film plane — 46.5 mm from the front surface of the lens mounting flange ⑪.



D. Infrared Photography

Both Nikon Series E and Nikkor lenses have an infrared photography focusing index **20** for shooting with black-and-white infrared film. The image is first focused through the viewfinder, then the lens focusing ring **23** is turned until the distance in front of the white focusing index is realigned with the red infrared index.



E. Depth of Field


When you focus on your subject, you will find that objects both in front of and behind it also appear to be in focus. This “zone” of focus is called depth of field. In general, to control depth of field, use the lens aperture ring **17** selectively, remembering that the lower the number of the aperture set (i.e., the wider the lens aperture), the “shallower” the depth of field, and vice versa. You can also use the color-coded depth-of-field indicators **21** of Nikon Series E and Nikkor lenses. The wider the gap between two identical colors (which match the color of the lens aperture number in use), the deeper the depth of field, and vice versa. Remember, when selecting an aperture based on depth of field, the shutter speed will change accordingly. Be careful that you don't use a shutter speed which is too slow for hand-held shooting or for moving subjects.



Lens set at $f/1.8$



Lens set at $f/8$



Lens set at $f/16$

VII. Special Accessories for the Nikon EM

A. Motorized Shooting with the Nikon MD-E Motor Drive

You don't have to be a pro to discover the excitement of motor-drive photography. The EM's special, equally compact and handsome accessory, the MD-E, makes motorized shooting easy for everyone. You have a choice of single-frame shooting or continuous shooting of up to about two frames per second. A red LED (light emitting diode) lamp at the back of the MD-E flashes to indicate that motorized shooting is in progress. And the motor automatically stops when all the frames have been exposed. It's that simple! Once you put on the motor you probably won't want to take it off! It's a natural accessory for all-around use.



B. Flash Photography with the Nikon SB-E Speedlight Unit

Slip the compact Nikon SB-E into your camera's recessed ISO-type flash unit hot-shoe **29**, and take great flash pictures automatically — at a predetermined shutter speed of 1/90 sec., with the shutter operation mode selector **2** on **AUTO**. It's so easy anyone can do it. A "ready-light" inside the camera's viewfinder lets you know when you're ready to shoot. Note that the flash photography bracket inside the viewfinder indicates a flash synchronization speed of 1/90 sec., no matter where the shutter speed needle is positioned. The SB-E provides features that no other flash can. It's the natural choice. It's compact enough to fit in a shirt pocket and really efficient. See it at your Nikon dealer. For flash photography with other electronic flash units, the shutter operation mode selector **2** is set to **M90**.



VIII. Other EM Accessories and Usable Lenses

Other Accessories



Camera Case

The CF-11 Camera Case is recommended for storing the Nikon EM with a Nikon Series E 50mm *f*/1.8 mounted. It has an attractive, durable finish.

Lens Hoods

The HR-4 and HR-5 Lens Hoods perfectly complement the Nikon Series E lenses. They prevent extraneous light from striking the lens surface and causing flare and ghost in the picture. Also useful for protecting the lens.



Eyepiece Adapter

Simply slide this adapter onto the EM's rectangular viewfinder eyepiece **32**, and you can use various Nikon viewfinder accessories such as eyepiece correction lenses, rubber eyecup, etc., to meet the requirements of various shooting situations.

Compartment Case

The FB-E Compartment Case has been specially designed to accommodate the Nikon EM with a Nikon Series E 50mm *f*/1.8 lens attached and other EM accessories such as Nikon Speedlight SB-E, Nikon Motor Drive MD-E, Nikon Series E 35mm *f*/2.5, 100mm *f*/2.8 and sundry items.

Nikon and Nikkor Lenses for the Nikon EM

(Wideangle)

Nikkor 13mm *f/5.6*
 Nikkor 15mm *f/5.6*
 Nikkor 18mm *f/4*
 Nikkor 20mm *f/3.5*
 Nikkor 24mm *f/2*
 Nikkor 24mm *f/2.8*
 Nikkor 28mm *f/2*
 Nikkor 28mm *f/2.8*
 Nikkor 28mm *f/3.5*
 Nikkor 35mm *f/1.4*
 Nikkor 35mm *f/2*
 Nikkor 35mm *f/2.8*

(Normal)

Nikkor 50mm *f/1.2*
 Nikkor 50mm *f/1.4*
 Nikkor 50mm *f/1.8*
 Nikkor 50mm *f/2*

(Telephoto)

Nikkor 85mm *f/2*
 Nikkor 105mm *f/2.5*
 Nikkor 135mm *f/2*
 Nikkor 135mm *f/2.8*
 Nikkor 135mm *f/3.5*
 Nikkor 180mm *f/2.8*
 Nikkor 200mm *f/4*
 Nikkor 300mm *f/2.8* IF ED
 Nikkor 300mm *f/4.5* IF-ED
 Nikkor 300mm *f/4.5*
 Nikkor 400mm *f/3.5* IF ED
 Nikkor 400mm *f/5.6* IF ED
 Nikkor 400mm *f/5.6* ED
 Nikkor 600mm *f/5.6* IF ED
 Nikkor 800mm *f/8* IF-ED

(Telephoto)

Nikkor 1200mm *f/11* IF ED

(Reflex)

Reflex-Nikkor 500mm *f/8*
 Reflex-Nikkor 1000mm *f/11*
 Reflex-Nikkor 2000mm *f/11*

(Zoom)

Zoom-Nikkor 28-45mm *f/4.5*
 Zoom-Nikkor 35-70mm *f/3.5*
 Zoom Nikkor 43-86mm *f/3.5*
 Zoom Nikkor 80-200mm *f/4.5*
 Zoom-Nikkor 50 300mm *f/4.5* ED
 Zoom-Nikkor 50-300mm *f/4.5*

(Fisheye)

Fisheye Nikkor 6mm *f/2.8*
 Fisheye-Nikkor 8mm *f/2.8*
 Fisheye Nikkor 16mm *f/3.5*

(Special)

PC-Nikkor 28mm *f/4*
 PC-Nikkor 35mm *f/2.8*
 Noct-Nikkor 58mm *f/1.2*
 Micro- Nikkor 55mm *f/3.5*
 Micro-Nikkor 105mm *f/4*
 Micro- Nikkor 200mm *f/4* IF

(Teleconverter)

Nikon Teleconverter TC-14
 Nikon Teleconverter TC-200
 Nikon Teleconverter TC-300

Nikon Series E Lenses

Nikon Series E 50mm *f/1.8*
 Nikon Series E 35mm *f/2.5*
 Nikon Series E 100mm *f/2.8*

Notes:

When using PC Nikkor lenses, it is important to note that exposure metering must be performed before the lens is shifted; should metering be performed after shifting, it may result in erroneous metering indication. First, note the shutter speed needle's position inside the viewfinder before shifting the lens. After shifting the lens, reset the ASA film speed scale **28** until the same shutter speed appears inside the viewfinder. For details, refer to the instruction manual of the lens.

Older Nikkor lenses which have been modified for AI operation and AI lenses of other than Nikon manufacture do not provide full performance with the Nikon EM, when used with the SB-E.

Nor can most AI modified 55mm *f/1.2* and 28mm *f/3.5* lenses be mounted on the Nikon EM; therefore, to prevent damage, don't attempt it.


If you mount the EM on a tripod with a large head, contact between the lens barrel and the head may make it impossible to operate the lens. In this case, use Nikon's special adapter between the camera body and the tripod head.

Caution: Auto Nikkor lenses and lenses of other manufacture which do not have the AI feature must not be mounted on the EM. Attempts to mount such lenses will damage the camera's AI indexing mechanism.

IX. Tips on camera care



Don't force your camera's controls — they are designed to work with a minimum of pressure.



Clean all lens surfaces periodically with a blower-type brush or lens tissue moistened with an approved photo lens cleaning liquid.



Avoid touching the camera's interior surfaces, especially the reflex mirror shutter curtains and film pressure plate.



If you drop the camera accidentally, take it to a Nikon authorized dealer or service center for immediate servicing.



Store your camera, lenses accessories in a cool, dry place. Remove the batteries when the camera or accessories are not to be used for an extended period.



Dispose of used batteries properly — never throw them into fire. For battery performance by brand, refer to manufacturer's literature.

X. Specifications

Type of camera	35mm single-lens reflex (SLR), aperture-priority automatic.
Picture format	35 mm (24 mm × 36 mm film size).
Lens mount	Nikon bayonet type.
Lenses usable	Nikon Series E 50 mm <i>f</i> /1.8 as Standard; other Series E lenses; AI-type Nikkor lenses and others.
Shutter	Electronically controlled, vertical-travel, metal focal-plane shutter; stepless speeds from 1 sec. to 1/1000 sec. when shutter operation mode selector is set to AUTO ; 1/90 sec. mechanical shutter speed when set to M90 ; B setting also provided for long exposures.
Film advance	Film winding lever provided completed stroke of 144° simultaneously advances film, cocks shutter and operates frame counter; choice of one continuous stroke or series of shorter strokes.
Viewfinder	Fixed eyelevel pentaprism full aperture viewing type with built in TTL exposure meter; shutter speed scale and exposure needle visible inside; ready-light lights up when SB-E or SB-10. Speedlight is in use, center of scale's bracket indicates 1/90 sec.; finder coverage approx. 92% of picture field; 0.86 ^x magnification with 50mm lens set at infinity.
Focusing screen	Fixed-type Nikon "K" screen; comprises matte fresnel field with central split-image range finder spot surrounded by microprism ring and 12mm-dia. reference circle which denotes area of center-weighted metering.
Reflex mirror	Instant return, non-lockable type.
Self-timer	Lever provided can be set for up to approx. 10-sec. exposure delay; setting cancellable before shutter release button is pressed.

Exposure measurement	Exposure TTL center-weighted exposure metering at full aperture; meter incorporates one silicon photo diode (SPD).
Metering range	EV 2 to EV 18 (i.e., $f/2$ at 1 sec. to $f/16$ at 1/1000 sec. at ASA 100 and with 50mm $f/1.8$ lens).
Exposure signal	“Beep-beep” warnings sound activated when shutter release button is pressed to fingerguard position if matching shutter speed for lens aperture set is approx. 1/30sec. and below, or approx. 1/1000sec. and above.
Exposure compensation	Approx. + 2EV when exposure compensation button is kept depressed as shutter release button is pressed.
Meter power source	Two 1.5V silver-oxide batteries (S-76 or SR-44 type) or one 3V lithium battery.
Meter ON/OFF switch	Meter switched on when shutter release button is pressed; stays switched on for several seconds after finger is lifted off button.
Battery power checker	LED lamp lights up to indicate sufficient power availability when power check button is pressed.
Film speed range	ASA 25 – 1600.
Frame counter	Shows number of frames exposed, automatically resets to “S” when camera back is opened; automatic operation starts from frame 1.
Film rewind	Manual; film rewind crank rotated after film rewind button is depressed.
Flash synchronization	Built-in ISO-type hot shoe, automatic flash sync at 1/90 sec. with SB-E Speedlight Unit which activates camera's ready-light when flash operation is ready; ready-light “blinks” to signal incorrect ASA/aperture combination; M90 shutter operation mode selector setting used with other electronic flash units, providing flash sync at 1/90 sec. bulb-type units not usable.
Motor drive coupling	Electrical contact and coupler built-in for operation with MD-E Motor Drive.
Camera back	Swings open when film rewind knob is pulled up; memo holder provided.
Body finish	Black.
Accessories provided	Camera body cap, triangular grommets for neckstrap and two 1.5V silver-oxide batteries.
Dimensions	135mm (W) × 86mm (H) × 54mm (D).
Weight	460g (body only).

* All specifications are subject to change without notice.